

armfield

Develop with us

Miniature-scale research & development technology

**CARBONATOR/FILLER
FILLER/CAPPER - (COUNTER PRESSURE FILLING STATION)**

**FT102X
FT104X**



explorearmfield.com

© Armfield Ltd. 2015
armfield

ISO 9001:2008
2YR EXTENDED WARRANTY

FEATURES

- Accurate control of filling and carbonating variables
- Option of filling and crown seal capping and/or screw top capping at a single station
- 30l process vessel, positioned at a convenient height
- Batch & continuous processing
- Throughputs up to 60l/h achievable (2l bottles) on FT102X
- Higher throughputs possible with add-on filling/capping system (FT104X)
- Wide range of cans or bottles can be used from 0.15l to in excess of 2l
- Evaluation service for customer cans and bottles
- CO₂ content in excess of 10g/l can be realised
- Enhanced colour touch screen control with help facility as standard
- In-bottle pressure measurement enables accurate and reproducible depressurisation
- Many parameters can be automated
- Carbonates foaming products
- Carbonates at any temperature between 4°C and 20°C
- Premix and postmix capability
- Adds protective gases (N₂ connection now standard)
- Improved cleaning programs with heater and spray ball
- Fills non-carbonated drinks

BENEFITS

- Easily reproducible test batches
- Very flexible and accurate
- No CO₂ loss during filling due to double stage cooling
- Easy to use: many functions automated
- Cost saving: for small test batches no production line is required
- Additional filling/capping head (FT104X) can be added at a later date
- Fill and cap different container styles to individual parameters on the same product run with the FT104X
- 32 preset programs

ISSUE - 5



Scan to learn more



Preparing carbonated beverages in the laboratory

The Armfield FT102X miniature-scale carbonator provides the ability to establish precise and repeatable parameters when carbonating in the laboratory, this can dramatically improve the speed with which new products are developed.

The FT102X is a totally new design including a large number of improvements and enhancements. In particular, special attention has been given to the ease of use, enhanced flexibility, reliability and improved Clean In Place (CIP).

Both premix and postmix operations are available from the standard machine, and an option is available to add the syrup for postmix automatically. Other options enable for deaeration of the product and evacuation of the bottles, continuous processing capability, and filling and capping (screw and/or crown) at a single station without removing the bottle.

The FT102X CARBOuator/FILLer is easy to install, set up and use. Colour touch screen control is used with a new graphical interface, enabling different carbonating and filling scenarios to be set and stored. The improved semi-automated cleaning programme takes the user step by step through the cleaning process and enables the unit to be made ready for another product or formulation.

The FT102X is ideally suited as a general purpose filling and carbonation installation for small laboratory applications. Used in conjunction with one of Armfield's FT74 UHT/HTST units, a complete drinks line can be created in the laboratory; consisting of heat treatment, carbonation, filling and capping.

Description of Operation

The FT102X is a combined carbonator and filler, designed primarily to enable R&D staff to prepare small quantities of beverages with reproducible characteristics and replicating the production product. The carbonation takes place using a recirculation pump to circulate the product from a 30l vessel through a heat exchanger system and a sinter tube where the CO₂ is introduced. The pressure in the carbonation vessel is controlled automatically by the plc. The vessel has two compartments, an outer compartment from which the product to be carbonated is drawn, and an inner compartment which contains the most recently carbonated product. When the inner compartment is full the contents overflow into the outer compartment.

The product is first chilled down to below the required carbonation temperature using a plate heat exchanger and then an in-line heater under PID control heats the product to an accurately controlled temperature. The plate heat exchanger requires a chilled water supply. This can either be the customers own supply or the Armfield FT63 recirculating process chiller (which can also be used with other products in the laboratory such as an Armfield FT74X).

The plate heat exchanger is able to be dismantled fully for cleaning. After carbonation, the product is passed to the filling head through a long tubular heat exchanger which further cools the product to prevent CO₂ release. The filling process takes place under PLC control. It consists of raising the bottle to the filling head, syrup dosing (option), evacuating the bottle (option), flushing the bottle with CO₂ (or N₂ if not carbonating), pressurising the bottle (CO₂ or N₂), counter-pressure filling the bottle, re-pressurising the vessel, allowing time for the contents to level-out, de-pressurising (or sniffling) and clearing the overflow.

Most functions of the FT102X are under PLC control and the operator interface is a touch screen control panel. It is possible to save and recall up to 22 sets of operating parameters to suit different products and containers. Each set of parameters can be allocated a descriptive name.

Filling and Capping Containers

A wide range of cans, PET and glass bottles can be handled.

The standard options can handle most containers from 0.15 to 2 litres, and larger containers (including 5l kegs) can usually be accommodated by simple modifications. However, we understand that all containers are different and we will be pleased to evaluate your containers in advance, particularly if screw capping is required

FT104X Filler/Capper - (Counter Pressure Filling Station)

The FT104X is a counter pressure filling station, which can be used as an add-on filling station for the FT102X.

- Simple enabling mod to FT102X enables FT104X to be added, either at time of order or at a later date. (Order code FT102X-46)
- FT104X adds an extra filling position to the one on FT102X, enabling a faster throughput
- One standard filling head included. Additional filling heads are available for cans or wider opening bottles.
- FT102X can still be used stand alone
- FT104X has its own control screen, making it easy to use and preventing any operator confusion regarding which head is being used.
- Simple connection to FT102X
- FT104X uses standard FT102X accessories, i.e. filling head adaptors, PET bottle carrier, filling tubes, centring rings etc.
- As the FT104X is independent from the FT102X filling system it is possible to use different filling parameters, different containers and/or different capping mechanisms if required
- FT104X can also be used as a stand alone counter pressure filler for filling from pressurised vessels

FT104X Optional Accessories

(see FT102X descriptions for more details)

- FT104X-2 Capper Enabling System
- FT104X-3 Crown Seal Capper (requires FT104X-2) (*)
- FT104X-4 Screw Cap Sealer Mechanism (requires FT104X-2)
- FT104X-6 Filling Head for Cans (*)
- FT104X-10 Vacuum System for Bottles (requires FT102X-10)
- FT104X-14 Syrup Dosing System
- FT104X-17 PET bottle neck Support (*)
- FT104X-19 Filling Head for Bottles, 25mm to 43mm (*)
- FT104X-35 Filling Tube for different head space (*)

(*) Note, these items are identical and interchangeable with the FT102X equivalents.

APPLICATIONS

- Soft drinks
- Beer
- Milk
- Juices and cordials
- Water
- Health and nutritional products



Examples of FT102X screenshots



Detail of Filling Head with optional Screw Capper Fitted

OPTIONAL FEATURES

OPTION	PRODUCT DESCRIPTION
FT102X-2 Capper enabling system	Incorporated into the filling station, this option enables the user to fit either the crown seal capper or the screw cap sealer into the capping head. It includes a pneumatic drive, which is used to move out the filling head and position the selected capper over the bottle. The two capping heads are interchangeable once installed, and can easily be fitted by the user.
FT102X-3 Crown seal capper mechanism (Requires FT102X-2)	The standard FT102X-3 works with the majority of bottles and crown caps. For other bottles we can normally produce a special capper head, order code FT102X-3-SPL. Armfield can test your bottles free of charge for suitability. (includes 1 set of calipers) .
FT102X-4 Screw cap sealer mechanism (Requires FT102X-2)	For use with splined plastic screw caps. Includes a motor drive with a variable torque setting to enable for a wide range of bottles and screw caps to be used. The motor limit current (hence the torque setting) is set electronically from the control panel. Different inserts can be fitted to the capping head to accommodate different types or sizes of cap. The standard insert fits many typical 28mm caps. Armfield can test your caps and bottles free of charge for suitability. For other bottles using splined caps we can normally produce a special insert tailored to the cap, order code FT102X-4-SPL. Note: For successful operation the FT102X-17 PET bottle holder must be used. For glass bottles a special holder (FT102X-17-SPL) can usually be provided.
FT102X-5 Centering Ring	The FT102X-5 is used to position the bottle centrally on the platform. Two of these acetal centering rings are included with each FT102X. These can be machined to suit the customer bottle size (if provided). Additional centering rings can be supplied for use with more bottle types. Order code FT102X-5-ZZ where ZZ is the hole size in mm.
FT102X-6 Filling head for cans (dia. up to 70 mm)	The standard FT102X-6 works with most cans, but some cans with unusual lips may need special attention. Armfield can test your cans free of charge for suitability.
FT102X-10 Vacuum system	Used for both deaerating the product (prior to carbonating) and for evacuating the bottles prior to filling. It includes the vacuum pump, the addition of a deaeration surface in the chamber and all the valves and controls for both processes. The evacuation parameters are integrated seamlessly with the other filling functions on the operator interface panel and are saved as part of the normal filling data.
FT102X-14 Syrup feed system	Comprising a feed vessel for syrup, peristaltic metering pump plus the various valves and facilities for automated syrup dosing. The syrup dosing parameters are integrated seamlessly with the other filling functions on the operator interface panel and are saved as part of the normal filling data.
FT102X-17 PET bottle neck support	Used to prevent crushing of containers during filling. The standard FT102X-17 works with most PET bottles with a 28mm nominal neck width. Armfield can test your bottles free of charge for suitability. For other bottles or different sizes we can produce a special support tailored to the bottle, order code FT102X-17-SPL.
FT102X-19 Filling Head for larger bottle openings	The standard filling head provided with the FT102X is suitable for bottles with an opening up to 25mm. The FT102X-19 enables bottles with a larger opening from 25 mm to 43 mm (O/D) to be filled.
FT102X-22 Hot Filling Connection	For filling directly from other process systems (This option is included in option FT102X-14).
FT102X-35 Filling tube	A replacement filling tube, which can be used to fill to a different headspace.
FT102X-44 Continuous Operation Facility	This option comprises a buffer tank and pump to enable product to be taken from a continuous process (such as an Armfield UHT system) and matched to the FT102X Carbonator/Filler. The buffer tank is filled from the feeding system and the pump transfers the contents to the FT102X carbonation vessel as required. An additional plate heat exchanger stage is incorporated into the FT102X to cool down the incoming product.
FT102X-46 Enabling system for FT104X	It is possible to use additional filling heads on an FT102X system in order to increase throughput, by adding an FT104X filling system. The FT102X-46 (ordered with the FT102X) enable an FT104X additional filling head to be added to the system at any time without modification to the FT102X.

Notes: The FT102X-2, -4, -10, -14, and -22 options must be specified at initial purchase and cannot be added later.

The FT102X-44 and -46 options require pipework changes, but can be installed on site (at extra cost).

armfield

Develop with us

Armfield R&D products include:

Hygienic connections as standard ✓

316 Stainless steel ✓

Advanced CIP ✓

CE certification ✓

Extended warranty as standard ✓



An ISO 9001 Company

Head Office:

Armfield Limited
Bridge House, West Street,
Ringwood, Hampshire.
BH24 1DY England

Tel: +44 1425 478781
Fax: +44 1425 470916
E-mail: sales@armfield.co.uk

U.S. Office:

Armfield Inc.
9 Trenton - Lakewood Road
Clarksburg NJ 08510
Tel/Fax: (609) 208-2800
E-mail: info@armfieldinc.com

follow us



twitter.com/Armfield_IFT
facebook.com/Armfielduk
linkedin.com/companies/armfield-limited
youtube.com/user/armfieldUK
explorearmfield.wordpress.com



FT102X Technical specifications

Gas pressure:	0-4 bar
Gas content:	0 - >10 g/l
Vessel capacity:	30 litre (certified in accordance with the Pressure Equipment Directive) (27 litre product capacity)
Contact surfaces:	316SS or food grade silicone hose
Gasses:	CO ₂ , N ₂ or any safe, non-flammable alternatives or mixtures. During cleaning compressed air is used

	Overall Dimensions cms			Shipping Specification	
	H	W	D	Gross weight	Volume
FT102X	175	75	80	372kg	2.1m ³
FT104X	175	75	80	350kg	2.1m ³
FT63	89	57	76	160kg	0.7m ³

Requirements

Electricity supply:

FT102X-A:	220-240V, 1ph, 10A, 50Hz
FT102X-G:	220-240V, 1ph, 10A, 60Hz
FT104X-A:	220-240V, 1ph, 10A, 50Hz
FT104X-G:	220-240V, 1ph, 10A, 60Hz
FT63(SS)-A:	220-240V, 1ph, 10A, 50Hz
FT63(SS)-G:	220-240V, 1ph, 10A, 60Hz

Water supply: Supply of chilled water at approx 1°C to 5°C below the carbonation temperature, @ 10l/min
The Armfield FT63 is ideal for use with the FT102X
Mains water @ 2 bar (min)

CO₂ (and/or N₂) supply with manual regulator, 6 bar

Compressed air supply with manual regulator, 6 bar

Ancillary Equipment

The Armfield range of UHT processing systems may be used to pasteurise the product prior to carbonation and filling. Units may be linked directly to the CARBONator/FILLer.

Available options include the FT74-30-MKIII (indirect heating using a plate heat exchanger), the FT74-20-MKIII (indirect heating using a tubular heat exchanger) and the FT174X (direct heating by injection of steam).



FT74-20-MKIII - Tubular Heat Exchanger
www.explorearmfield.com/data/ft74xts

FT174X - Modular Miniature Scale HTST/UHT Process System
www.explorearmfield.com/data/ft174x

Miniature-scale R&D technology
modular R&D system

The Armfield range includes HTST/UHT/aseptic systems, carbonator/filler/cappers, spray dryers/chillers, multifunction batch processors, ice cream freezers, margarine crystallisers, extractors, edible oils processors and more. For further information about our products and services, or to book a trial at one of our trials facilities, please contact us.